

DT4280 Series

DIGITAL MULTIMETER

Remote Operation Manual

HIOKI E. E. CORPORATION

Aug. 2021

Revised edition 4

1.Remote Interface Overview

2.Interface Parameters

3.About Command

3.1. Terminator

3.2. Return result

+

3.3. Data Types

4. Summary of Commands

[illegible]

5. Detail of Commands

5.1. Description of Commands

[illegible]

--	--

[illegible]

[illegible]

	
	
	

[illegible]

5.4. Index of threshold of diode test

[illegible]

5.5. Index of standard impedance of dBm

[illegible]

5.6. Count value of abnormal data

6. Compatible command with earlier products

	:

Please note